

# YEAR 2010 SPEEDPLAY ROAD SHOE COMPATIBILITY GUIDE\*\*\*

## SHOES COMPATIBLE WITH FACTORY-INSTALLED 1-F AND 1-R SNAP SHIMS

\* Bont 3 hole / \* Bontrager Nylon / \* Exustar / Gaerne / \* Louis Garneau EXO Jet / \* Mavic / \* Northwave / \* Scott Nylon / \* Sidi Carbon Lite \* See excepted models below

## COMPATIBLE SHOES REQUIRING ALTERNATIVE CLEAT INSTALLATION

adidas	2006 & earlier	Use 1-F & 1-R Snap-Shims
Answer	2009 & earlier	Use 1-F & 1-R Snap-Shims
Bontrager - Carbon	Current year & earlier	** Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Carnac	Current year & earlier	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap Shims.
Carnac Insert-type	Current year & earlier	Omit base plate. Use Carnac-supplied UCS3 insert. Requires Speedplay 4x15-8 Cleat Fastening Screws (Part #13015).
Diadora	Current year & earlier	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap Shims.
Diadora Alu	Current year & earlier	Call Speedplay for installation instructions.
Diadora Multiped	Current year & earlier	Omit base plate. Use Diadora-supplied Time/Speedplay insert.
DMT	Current year & earlier	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap Shims.
DMT insert-type	Current year & earlier	** Remove Snap-Shims from base plate. Sole must be modified to allow rearward cleat adjustment. See photo at <a href="http://www.speedplay.com">www.speedplay.com</a> .
DMT	2009 & earlier	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Duegi	2008 & earlier	Use 1-F & 1-R Snap-Shims
Exustar	Current year & earlier	Use 1-F & 1-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Kuips	Current year & earlier	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap Shims.
Lake	Current year & earlier	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap Shims.
Look	2007 & earlier	Use 1-F & 1-R Snap-Shims
Louis Garneau Carbon Ergo	Current year & earlier	Use 1-F & 1-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Louis Garneau	2007 - 2010	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap Shims.
Luck	2009 & earlier	Use 1-F & 1-R Snap-Shims
Nalini CARBONALINI sole	2009	Use 1-F & 1-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Nalini	2008	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap Shims.
Nalini	2006 - 2007	Call Speedplay for installation instructions.
Nike	2009 & earlier	Use 1-F & 1-R Snap-Shims
Northwave Centurion, Mirage, Solo, Diana Road, Husky	Current year & earlier	Omit base plate. Use Northwave-supplied Time/Speedplay insert. Requires 4x13-8 Cleat Fastening Screws (Part #13295) available from Speedplay.
Northwave Aerator & Genetix	2006 & earlier	** Requires #3 shim Kit (Part #13395 sold separately). Remove 1-F & 1-R Snap Shims. Install 3-F & 3-R Snap-Shims.
Pearl Izumi	Current year & earlier	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap Shims.
Pearl Izumi I Beam Sole	Current year & earlier	Use 1-F & 1-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Scott - Carbon	Current year & earlier	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap Shims.
Shimano	Current year & earlier	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap Shims.
Shimano Carbon-Fiber	2004 & earlier	Use 1-F & 1-R Snap-Shims. Compatible only with Zero Pedal Systems.
Sidi - Carbon Comp	Current year & earlier	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap Shims.
Sidi - Carbon Millenium III	Current year & earlier	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap Shims.
Sidi NonCarbon-Fiber	2004 & earlier	** Requires #3 shim Kit (Part #13395 sold separately). Remove 1-F & 1-R Snap Shims. Install 3-F & 3-R Snap-Shims. Do NOT use the Sidi-supplied insert.
SixSixOne	2008 & earlier	Use 1-F & 1-R Snap-Shims
Specialized (FACT Soles & Nylon/Glass Reinforced Soles)	2010	** Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Specialized Full Carbon Pro Models	2009	Use 1-F & 1-R Snap-Shims.
Specialized NON Carbon Models	2009	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap-Shims.
Specialized	2007 - 2008	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap-Shims.
Specialized	2001 - 2006	Use 1-F & 1-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Time - Carbon	Current year & earlier	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap Shims.
Time - Nylon	Current year & earlier	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Time Carbon-Fiber	2008	Use 1-F & 1-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Time	2006	Use 1-F & 1-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Vittoria	2009 & earlier	Use 1-F & 1-R Snap-Shims
Wellgo	Current year & earlier	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap-Shims.
Xpedo	Current year & earlier	** Remove 1-F & 1-R Snap Shims. Install 4-F & 4-R Snap-Shims.

**\*\* Ensure the factory-installed cleat nuts remain in the base plate.**

### Shoes with 4-hole cleat pattern (base plate not used).

adidas / Bont / DMT / Lake / Rocket 7	Current year & earlier	Omit base plate. See 4-hole carbon-fiber soles.
Northwave Evolution	Current year & earlier	Omit base plate. Requires Speedplay 4x15-8 screws (Part #13015). See 4-hole Carbon-Fiber Soles.

## INCOMPATIBLE SHOES

adidas	2007 - 2008	Northwave Carbonio	Current year & earlier	
DMT Mag Force & Mag Light	2008	Scott Full Carbon Power Transfer Sole	2009	
Exus	Current year & earlier	Scott - Road Ltd.	Current year & earlier	
Lake CX 401	Current year & earlier	Shimano WITHOUT 3-Hole (Look) configuration	Current year & earlier	
Lake 115 & 125	Current year & earlier	Shimano Carbon Fiber	2004 & earlier	X Series incompatible
Mavic	2009	Time Elan	Current year & earlier	
Nalini	2005 & earlier	All MTB shoes and road shoes with MTB-type lugged soles	Current year & earlier	

**4-Hole Carbon Fiber Soles:** Must use Stainless Steel Wear Protector Shim Kit (Part #13290), sold separately and available from Speedplay, to prevent contact between the pedal body and the carbon-fiber sole. Carbon fiber is a poor wear surface and unless a wear protector is used, damage to both the pedals and shoes will result.

**WARNING!** - Do not use the Snap-Shim Cleat mounting screws with any previous models of Speedplay X cleats including the Slim Line Cleat. The Snap-Shim Cleat mounting screw heads are too small and may pull through the older base plates. This may cause the cleat to pull off the shoe causing a fall that may result in severe injury.

**\*\*\* See detailed photos of select sole mountings and the latest updates for shoe compatibility at [www.speedplay.com](http://www.speedplay.com) or call the Speedplay Tech Department at 1-800-468-6694 (PST).**